FRONT SIDE



3 Adjustable Fan Blade 6 Charging Indicator

9 Spray Opening Key LED Light Switch Air Inlet

Fan Indicator

8 Fan Button

Type-C Port

cooling effect!

Indicator Status Description


Indicator Status	Charging Indicator	Fan Indicator	Spray Indicator
The red light is on	Charging	Slow Speed	_
The green light is on	_	Medium Speed	_
The blue light is on	Full charge	Fast Speed	
The white light is on	_	_	Humidifier on
The red light is blinking	The battery is low	_	_
Light Off	Not charging/ Out of battery	Not On	Humidifier off

How To Start The Fan/Humidifier/Light Function

- 1. The fan is powered using a Type-C charging cable to connect the fan with the charging adapter or your computer's USB port.
- 2. Press the Fan button to start, Press the Fan and Spray Indicator buttons at the same time to activate the humidifier. Push the Fan Indicator button to speed up the power of the fan. Use the Fan button again to shut off the device.
- 3. When the fan is on, press the Spray Indicator button to turn off the humidifier separately. When the device detects that there is not enough water in the water tank, the humidifier function will automatically shut
- 4. Press the LED Light Switch button to cycle through the different colors. Hold the button to keep the light a steady color. Push the button again to shut it off.

Tip: Soak the Water Absorption Curtain before using for a better


BACK SIDE




Attentation: After the product is filled with water, it must remain

upright to prevent any water from penetrating the circuit board or fan.

How To Replace The Water Curtain



2. Remove the old water




3. Replace the water absorption 4. Push the front grill back in

Tips: If not using the fan for a long time, drain the water from the tank and blow-dry the curtain. Water absorption curtains generally last 6-8 months. Replace accordingly based on personal use.

Safety Precautions

- Check device voltage compatibility with this product before using it;
- Do not disassemble product or handle it roughly;
- Avoid exposure to heat or direct sunlight;
- Keep product out of reach of children and pets;
- Please use included Type-C Cable and 5V/2A adapter;
- Regularly clean the inside and outside of the fan to prevent dust from accumulating. Before cleaning the fan, be sure to turn off the product and unplug the power cord;
- Do not put your fingers or hard objects into the intake/outlet;
- Stop using the product if it starts to malfunction.

The device complies with the European Directives 2014/30/EU.



This device complies with part 15 of the FCC Rules.

封面

IM Dimensions: 148 x 105mm Double Side Printing Black&White